

HG[®]

garden

HG plastic garden furniture restorer

Plastic garden tables and chairs, that have become grimy or extremely dull, can be brought back to life by using HG "plastic garden furniture restorer".

Directions for use: First remove surface dust and dirt with HG "powerful garden furniture cleaner", before wiping off and allowing to dry. Shake the bottle well before use. Apply a little of HG "plastic garden furniture restorer" and wipe over with a cloth. Take attention to wipe over in one direction as the product has a slight polishing effect. Always use a clean cloth when applying HG "plastic garden furniture restorer". Afterwards wipe off the treated surface with a damp cloth. Finally buff with a clean cloth (still in one direction) to obtain a clean, bright gloss. If necessary, repeat the treatment. For regular cleaning HG "powerful garden furniture cleaner" is recommended.

Attention: Transport and store the bottle upright. Coloured plastic garden furniture should be tested first on a small inconspicuous area to check that it is colour fast. Do not use in bright sunlight. Shake well before use. HG "plastic garden furniture restorer" only works on lightly tarnished furniture. Treat plastic furniture in its entirety rather than just small areas to ensure an even gloss. Keep in a frost-free area. • Medical personnel can request the data sheet via +31 (0)36 54 94 777 • The consumer's information sheet can be obtained via www.HG.eu • 1,16 percent of the mixture consists of component(s) of unknown toxicity.

QUESTIONS ABOUT CLEANING AND MAINTENANCE? www.HG.eu

Biodegradable according to regulation 648/2004/EC

plastic garden furniture restorer



renovates grimy synthetic furniture

500 ml e



HG[®]

garden

HG plastic garden furniture restorer

contains a.o.:

non-ionic surfactants	5-15%
aliphatic hydrocarbons	< 5%

preservation agents:
Benzisothiazolinone,
Methylisothiazolinone



0512600105006 1510



WARNING H319
Causes serious eye irritation. **P101**- If medical advice is needed, have product container or label at hand. **P102**- Keep out of reach of children. **P264**- Wash hands thoroughly after handling. **P305+P351+P338**- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

Made in The Netherlands
by HG International b.v.,
Damsluisweg 70,
1332 EJ Almere,
The Netherlands,
Tel.: +31 (0)36-5494700

plastic garden furniture restorer



renovates grimy synthetic furniture

500 ml e